



**THE ERGONOMIC NECK SUPPORT**  
Comfortable & Easy To Wear With Memory Foam  
**Taking The Pain Out Of Overhead Work**

**Prevents Over Extension When Working Overhead, Reducing Neck Pain and Risk of Injury**



**Some of the Many NeckAid Users:**

- Crane Operators
- Overhead Assembly Workers
- Painters
- Automotive & Airline Workers
- Building and Transportation
- Maintenance Workers
- Utility Crews & Ceiling Installers
- Steel Workers & Electricians
- Back To Work Rehabilitation
- Injury Prevention Programs

**INSTRUCTIONS: Strapping & Adjusting the NeckAid Head Support for Proper Fit**

- Place the NeckAid behind the head-wide part across the upper back
- Bring head through the straps - straps should cross the chest
- Adjust chest buckle connecting the two main straps to just below the sternum
- Attach suspender clips to pants, belt, harness or tool belt - at the sides for added comfort
- Some users may need to shorten main straps where they attach to the NeckAid
- Adjust the straps so the head rests comfortably on the NeckAid head support
- When using the NeckAid head support don't force the head back once contact is made
- We recommend using the head support as a guide for proper posture as well as support, working with the eyes shifted upward rather than centered in sockets



- The higher the NeckAid is positioned on the upper back the more the head will be supported

**Distributed by NeckSolutions.com – A Division of PostureMed**

Hand wash in cold water using gentle soap - no chlorine bleach - dry flat